



USA

---

## Toaster Oven

---

### OPERATING INSTRUCTIONS

---

# ET-WMC22

## INDEX

IMPORTANT SAFEGUARDS .....	2
BEFORE USE .....	6
PARTS NAMES .....	7
HOW TO USE .....	8
COOKING TIPS .....	9
COOKING TEMPERATURE AND TIME GUIDELINES .....	10
RECIPES	
Roasted Vegetables .....	11
Oatmeal Raisin Cookies .....	11
CLEANING AND MAINTENANCE .....	12
HOW TO ATTACH AND REMOVE PARTS .....	13
TROUBLESHOOTING GUIDE .....	14
SPECIFICATIONS .....	15
REPLACEMENT PARTS .....	15

# IMPORTANT SAFEGUARDS

Be sure to follow the instructions.

## WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- 1 Read all instructions thoroughly.
- 2 Avoid touching hot surfaces. The handles and knobs are provided for your safety and protection.
- 3 To prevent hazardous operation or electric shock, do not immerse power cord, power plug, or toaster oven in water or other liquids.
- 4 Close supervision is necessary when the appliance is used by or near children.
- 5 Unplug from outlet when the appliance is not in use and before cleaning. Allow the appliance to cool before adding or removing parts, and before cleaning the appliance.
- 6 Do not use or operate the appliance with a damaged cord or plug. If the appliance malfunctions or has been damaged in any manner, unplug the appliance and return it to the nearest authorized service facility or dealer for examination, repair or adjustment.
- 7 The use of accessories or attachments not recommended by the appliance manufacturer may be hazardous or may cause malfunction.
- 8 Do not use outdoors.
- 9 Keep the power cord away from hot surfaces and do not let the cord hang over the edge of tables or counters.
- 10 Do not place the appliance on or near a heated surface such as a gas or electric stove, or in a heated oven.
- 11 Always use extreme caution when moving appliances containing hot contents or liquids.
- 12 To disconnect, turn the Timer Dial to OFF and unplug the Power Plug from the electrical outlet. Never pull on the Power Cord.
- 13 Do not use the appliance for other than intended or specified purposes.
- 14 Oversized foods or metal utensils must not be placed inside the oven as they may create a fire or risk of electric shock.
- 15 A fire may occur if the appliance is covered or touching flammable materials, including curtains, draperies, walls, and the like, when in operation. Do not store any items on top of the appliance when in operation.
- 16 Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts involving a risk of electric shock.
- 17 Extreme caution should be exercised when using containers constructed of materials other than metal or glass.
- 18 Do not store any materials other than the manufacturer's recommended accessories inside the oven when not in use.
- 19 Do not place any of the following materials inside the oven: paper, cardboard, plastic, etc.
- 20 Do not cover the crumb tray or any part of the appliance with metal foil. This will cause overheating of the appliance.

## SAVE THESE INSTRUCTIONS

### THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

#### NOTE:



- A. A short power cord is provided to reduce the risk of becoming entangled in or tripping over it.
- B. Extension cords may be used if care is exercised in their use.
- C. When an extension cord is used:
  - (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and
  - (2) the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

# IMPORTANT SAFEGUARDS (cont.)

These WARNINGS and CAUTIONS are intended to prevent property damage or personal injury to you and others.







■ The degree of danger or damage by the misuse of this product is indicated as follows:

 <b>WARNING</b> Indicates risk of serious injury or death.	 <b>CAUTION</b> Indicates risk of injury, household or property damage if mishandled.
---	--

■ Prohibited or required actions are indicated as follows:

 Indicates a prohibited operation.	 Indicates a requirement or instruction that must be followed.
---	---

## **WARNING**

 <b>Do not modify the product. Only a repair technician may disassemble or repair this product.</b> Attempting to do so may cause fire, electric shock or injury. Make any repair inquiries to Zojirushi Customer Service.	 <b>Use only an electrical outlet rated at 15 amperes minimum, and do not plug other devices into the same outlet.</b> Plugging other devices into the same outlet may cause the electrical outlet to overheat, resulting in fire.
 <b>Do not immerse in water or splash with water.</b> Doing so may cause short circuit or electric shock.	<b>Insert the Power Plug completely and securely into the electrical outlet.</b> A loosely inserted Power Plug may cause electric shock, short circuit, smoke or fire.
 <b>Do not plug or unplug the Power Plug if your hands are wet.</b> Doing so may cause electric shock or injury.	<b>If the blades or surface of the Power Plug become soiled, wipe them clean.</b> A dirty Power Plug may cause fire.
 <b>Do not allow children to use the product unsupervised. Keep it out of the reach of infants.</b> Children and infants are at risk of burns, electric shock or injury.	<b>Stop using immediately if you notice any of the following symptoms indicating malfunction or breakdown.</b> Continued use of the product may cause smoke, fire, electric shock or injury.
<b>Do not use a power source other than 120V AC.</b> Using any other power supply voltage may cause fire or electric shock.	<ul style="list-style-type: none"> <li>• The Power Plug or Power Cord has become very hot.</li> <li>• The Power Cord is deeply damaged or deformed.</li> <li>• The electricity turns on and off when the Power Cord is touched or moved.</li> <li>• A Heater is broken.</li> <li>• There is a burning smell.</li> <li>• A part is cracked, rattling or loose.</li> <li>• You feel a tingle or slight electrical shock.</li> <li>• The product does not operate even though the Timer Dial is turned to a setting other than OFF.</li> <li>• The Timer Dial cannot be turned to OFF and the product remains on. etc.</li> </ul>
<b>Do not use the product if the Power Cord or Power Plug is damaged or if the Power Plug is loosely inserted into the electrical outlet.</b> Doing so may cause electric shock, short circuit or fire. <div style="text-align: center; margin-top: 10px;">  </div>	<b>If any of the above occurs, unplug the product immediately and contact Zojirushi Customer Service for check-ups and/or repairs.</b>
<b>Do not damage the Power Cord. Do not bend, pull, twist, fold, or attempt to modify the Power Cord. Do not place it on or near high temperature surfaces or appliances, under heavy items or between objects. A damaged Power Cord can cause fire or electric shock.</b>	<b>This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.</b>
<b>Do not use the product near flammable items or items vulnerable to heat, such as curtains.</b> Doing so may cause fire.	
<b>Do not use the product with oil in the Baking Tray.</b> Doing so may cause fire.	

• The illustrations used in these Operating Instructions may vary from the actual product you have purchased.

# IMPORTANT SAFEGUARDS (cont.)

## ⚠ CAUTION

### Be sure to observe the following to prevent fire.



- **Never leave the product unattended during operation.** Foods may catch on fire.
- **Do not overheat foods.** Doing so may cause fire.
- **Do not use for other than the intended purposes.** Doing so may cause fire.
- **Do not cook breads or waffles topped with butter or jam.**  
Oily or sugary foods burn easily and may cause fire.
- **Do not cook oily foods such as meat, fish or fried foods directly on the Rack.**
  - When cooking meat or fish, wrap in aluminum foil and place on the Baking Tray.
  - Oil may leak even when using aluminum foil, so be sure to cook the foods on the Baking Tray.
  - Otherwise oil from the foods may drip or spatter and cause fire.
- **Do not operate the product with objects on top or underneath it.**  
The product or object may deform, melt or cause fire.
- **Do not operate the product with the Door open.** Foods may catch on fire.
- **Do not let foods touch the Heaters.** Doing so may cause fire.
- **Do not use with the Rack removed.** Doing so may cause fire.



- **Be sure to attach the Crumb Tray.** Failure to do so may cause fire.
- **Always use the Baking Tray for foods that may fall through the Rack.**  
Not doing so may cause fire.

### If foods cause smoke or catch fire...



- **Turn the Timer Dial to OFF immediately and unplug the Power Plug.**  
If foods catch fire, do not open the Door until the flame extinguishes. Do not attempt to put out the fire by pouring water on it, as it may cause the Glass Window to break.

<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p><b>Do not touch hot surfaces (all parts except the Temperature Dial, Timer Dial, and Door Handle) during use or shortly after use.</b></p> <p>Touching hot surfaces may cause burns.</p> </div> </div>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p><b>Unplug the Power Plug from the electrical outlet when the product is not in use.</b></p> <p>Leaving the Power Plug in an electrical outlet may cause the insulation to become damaged, resulting in electric shock, short circuit or fire.</p> </div> </div>
<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p><b>Do not place or use the product on unstable surfaces or on surfaces that are vulnerable to heat.</b></p> <p>Doing so may cause injury or fire.</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Do not use the product near walls or furniture.</b></p> <p>Heat may damage, discolor or deform walls or furniture. (See pg.6 "INSTALLATION GUIDELINE")</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Do not use the product where it may come into contact with water or near heat sources.</b></p> <p>Doing so may cause electric shock, short circuit or fire.</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Do not hold or carry the product while it is still hot.</b></p> <p>Touching hot surfaces may cause burns.</p> </div> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p><b>Do not directly heat canned or bottled foods.</b></p> <p>The can or bottle may burst and cause burns or injury.</p> </div> </div>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div> <p><b>During cooking, move birds and small animals that may be sensitive to smoke or smells to other rooms, and open windows or turn on exhaust fans.</b></p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Always unplug the product by holding the Power Plug, not by pulling the Power Cord.</b></p> <p>Pulling the Power Cord to unplug the product may cause electric shock, short circuit or fire.</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Allow the product to cool down before cleaning.</b></p> <p>Touching hot surfaces may cause burns.</p> </div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;"> <p><b>Be sure to clean after every use.</b></p> <p>Food crumbs and oil left behind may cause smoke or catch fire.</p> </div> </div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p><b>If the Power Cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons to avoid hazards.</b></p> </div> </div>

# IMPORTANT SAFEGUARDS (cont.)

## IMPORTANT

- **Do not cook breads or waffles topped with butter or jam.** Doing so may cause fire.
- **Do not overheat foods.** Doing so may cause fire.
- **Be sure to watch the following foods while cooking. (Never leave the product unattended.)**  
These foods burn easily and may catch fire.
  - Tempura, butter-enriched rolls, cookies and other oily or sugary foods
  - Thinly sliced bread
  - Thinly sliced French bread
  - Rice cakes
  - Sliced and dried rice cakes
  - Meat, fish and fried foods, etc.
- **Do not use parchment paper, baking paper, or paper cake/cupcake liners.**  
Doing so may cause fire.
- **Do not use resin or silicone containers.** Doing so may cause fire.
- **When using aluminum foil, be careful that it does not touch the Heaters or extend from the Baking Tray.**  
If aluminum foil blocks part of the Oven Interior or touches the Heaters, it may cause fire, breakdown or damage to the product.




If foods cause smoke or catch fire, do not open the Door immediately. Return the Timer Dial to OFF, unplug the Power Plug, and allow the product to cool down before opening the Door.

- **Do not splash water on the Door (the glass) when hot.**  
The Glass Window may break and cause injury.
- **Be careful not to apply strong impact to or otherwise damage the Door (the glass). Do not apply strong force to the Door Handle.**  
Doing so may break the Glass Window or cause injury, breakdown or damage to the product.
- **Do not place objects on the opened Door.**  
Doing so may cause breakdown or damage to the product, or the product may tip and food may slide out.
- **Do not rapidly open and close the Door.** The Rack may come loose.
- **Do not use the Rack or Baking Tray with a gas stove or other cooking equipment.**  
Doing so may cause deformation or damage.
- **Be sure to observe the following to prevent damage to the Baking Tray.**
  - Do not use rigid utensils such as metal spatulas, knives, or nylon brushes.
  - Line the Baking Tray with aluminum foil before placing heat-resistant dishes on top.
  - Do not turn on the product without food inside.
- **Do not turn on the product with the Crumb Tray, Rack or Door removed.**  
Doing so may cause fire, breakdown or damage to the product.
- **Do not line the Crumb Tray with aluminum foil.** Doing so may cause breakdown or damage to the product.
- **Do not place the product over direct flame (such as a gas stove top), or on top of electric or induction heating (IH) cookers.** Doing so may cause fire, breakdown or damage to the product.
- **Do not steam foods.** The steam may cause breakdown or damage to the product.
- **This product is intended for household use and similar applications listed below:**
  - Staff (employee) kitchen areas in shops, offices and other working environments.
  - ※ This product is not intended for use by many unspecified people for a long period of time.This product must not be used in the following areas:
  - Farm houses.
  - By clients in hotels, motels and other residential type environments.
  - Bed and breakfast type environments.

# IMPORTANT SAFEGUARDS (cont.)

## INSTALLATION GUIDELINE


- Be sure to keep the distance in the illustration between the product and flammable items such as wooden walls and furniture, to prevent fire. (Not doing so may cause fire.)
- Leave **at least 12 inches (30cm)** space in front and either to the right or left side of the product. (Do not place the product near walls or place obstructions around the product.)
- Make sure that vinyl cloths and walls or furniture etc. made of resin or other heat-sensitive materials are even further away than specified in the illustration. (The heat may deformation or discolor such objects.)



## BEFORE USE

This product is used to toast sliced bread and heat pizza, etc.  
Do not use the product for other than the intended cooking purposes, or for commercial purposes.

- Be sure to remove all packaging materials inside the oven before use.
- Before using the product, make sure that the Timer Dial is set to OFF and insert the Power Plug into an electrical outlet.
- When the product is used for the first time, it may produce some smoke, but this does not indicate a malfunction.




### The Heaters may turn on and off during use. This does not indicate a malfunction.


- When the Oven Interior becomes hot, the thermostat operates and the Heaters automatically turn on and off to prevent the product from overheating.
- When using consecutively, the thermostat operates and the frequency of the Heaters turning on and off increases or the Heaters may not turn on for a while, so the cooking time may need to be extended. Watch the food and adjust the cooking time accordingly.

# PARTS NAMES

● The Rack, Door and Crumb Tray can be removed. (See pg. 13)




● Please remove the Twist Tie holding the Power Cord before use.  
● Do not use the Power Cord bundled up. Doing so may cause the Power Cord to become excessively hot, resulting in malfunction.



## Accessory

Baking Tray (1 pc)



## CAUTION

- The Baking Tray may make noises due to warping during cooking, but this does not indicate a malfunction.
- Line the Baking Tray with aluminum foil to help prevent messes and/or stains.  
When heating pizza or fried foods, press the aluminum foil with your fingers to form it to the shape of the Baking Tray for better cooking results.
- The pattern from the Baking Tray may appear on the bottom of foods.

# HOW TO USE

## 1 Insert the Power Plug into an electrical outlet, arrange the foods evenly on the Rack, and close the Door.


- Use the Baking Tray for juicy foods.  
The Baking Tray may warp when heated by foods.  
Arrange foods evenly or place them in a heat-resistant dish.
- Do not place foods on the opened Door.
- Foods may cook unevenly depending on how they are placed, so arrange the foods evenly as shown below.
- Arrangement as shown may not be possible depending on the food size, type, shape, etc.

### When reheating...

Always line the Baking Tray with aluminum foil when reheating pork cutlets, croquettes or other fried foods.

### BREAD

- 1 slice:  
Place in the center.
- 2 slices:  
Arrange evenly.




### PIZZA

Place on the Baking Tray lined with aluminum foil.



### Commercially packed MOCHI

Arrange evenly.




- Use the Baking Tray for freshly pounded and homemade rice cakes.

## 2 Set the Temperature Dial and the Timer Dial.

- ① Set the Temperature Dial according to the foods to be cooked.
- ② When the Timer Dial is turned, the Timer Light turns on and cooking begins.  
(See pg. 10 for "COOKING TEMPERATURE AND TIME GUIDELINES".)

- Preheating is not necessary.
- Turn the Timer Dial to OFF before removing or inserting foods.
- Do not overheat foods. Doing so may burn or cause the foods to catch fire.  
Be especially careful when cooking oily or sugary foods such as cookies.

When setting the Timer Dial to "10" or less, first turn the Timer Dial past "11", and then turn it to the desired time.



## 3 Cooking completes.

When the set time has passed, a "ding" sounds and cooking is finished. (The Timer Light turns off.)

- The Baking Tray and other parts are hot, so use an oven mitt or other cloth when removing foods.
- Unplug the Power Plug from the electrical outlet after use.  
(Always hold the Power Plug. Never pull on the Power Cord.)

### To stop cooking partway...

Turn the Timer Dial to OFF. (The Timer Light turns off.)




# COOKING TIPS

POINT  
1

## Use aluminum foil.

- Wrap foods that may spatter oil in aluminum foil.
- Cover foods that burn easily or thick foods with aluminum foil once they are browned.



POINT  
2

## Use the Baking Tray.

- Use the Baking Tray for small foods that may fall through the Rack, foods that lose their shape or melt (freshly pounded rice cakes, cheese, etc.), or foods with ingredients that may spill out.

POINT  
3

## When heating frozen foods...

- Always use commercially frozen foods that are for toaster ovens, and refer to the “COOKING TEMPERATURE AND TIME GUIDELINES”. (See pg. 10)
- Be careful when cooking commercially frozen croquettes, as the contents may pop out if overheated.
- Removing frost from the surface of foods reduces uneven cooking.
- If foods do not warm up, leave them inside the oven for a period after the cooking time ends to warm using residual heat.

POINT  
4

## When toasting frozen breads...


- Once the surface is browned, turn the Timer Dial to OFF and leave the bread inside the oven for an additional 2 to 3 minutes (because the inside of the bread does not heat easily even though the surface is toasted).

POINT  
5

## When toasting rice cakes (MOCHI)...

- Remove rice cakes from the Rack as soon as they are cooked. (Otherwise the rice cakes may stick to the Rack.)
- Depending on the type of rice cakes, the inside may be hard even though the surface is browned. In that case, leave the rice cakes inside the oven for an additional 1 to 2 minutes.
- Thinly-sliced rice cakes burn easily, so set a shorter cooking time. They also easily catch fire, so never leave the product unattended, and watch while cooking.
- Use the Baking Tray for freshly pounded and homemade rice cakes and watch while cooking.

Otherwise the rice cakes may stick to the Rack.



POINT  
6

## When heating tempura...

- Tempura burns easily depending on the size, so adjust the temperature and cooking time while watching the cooking condition.
- Always place tempura on the Baking Tray lined with aluminum foil.

# COOKING TEMPERATURE AND TIME GUIDELINES

- The cooking temperatures and times noted below are guidelines. Never leave the product unattended, and watch the foods while cooking. Be especially careful when cooking a small amount of food, as the food may burn easily or catch fire when cooked for the times noted below.
- The actual cooking time and how the food is cooked will vary according to the room temperature, the temperature inside the oven, the temperature, size, amount and type of foods, the container used, and other factors.
- When cooking consecutively, please watch the progress and make adjustments as necessary.
- When using consecutively, the thermostat operates and the frequency of the Heaters turning on and off increases or the Heaters may not turn on for a while, so the cooking time may need to be extended. Watch the food and adjust the cooking time accordingly.
- The cooking time for toast is set so that the bottom side becomes a light brown color.

Type	Food	Amount	Temperature Setting	Cooking Time* (Approx. Minutes)	Baking Tray (Lined with Aluminum Foil)	Notes
Toast	Toast	2 slices	TOAST	3-4	—	• Set the cooking timer shorter when toasting 1 slice.
	Rice Cakes	3 pieces (5.3 oz. / Approx. 150g total)	450	4.5-5.5	—	• Use rice cakes at room temperature.
Frozen Foods	Frozen Pizza	1 pizza (6" / Approx. 15cm)	425	16-19	Required	• Cover with aluminum foil once it reaches your desired color.
	Frozen French Fries	20 pieces (4.2 oz. / Approx. 120g total)		12-14	Required	—
	Frozen Tater Tots	12 pieces (3.5 oz. / Approx. 100g total)		14-16	Required	—
	Frozen Chicken Nuggets	9 pieces (5.6 oz. / Approx. 160g total)	400	12-15	Required	—
	Frozen Pizza Pocket	1 piece (4.6 oz. / Approx. 130g)	350	28-30	Required	• Cover with aluminum foil once it reaches your desired color.
Reheat	French Fries	10 pieces (0.9 oz. / Approx. 25g total)	450	1.5-2.5	Required	—
	Pizza	1 slice (4.6 oz. / Approx. 130g)	350	4-7	Required	• Cover with aluminum foil once it reaches your desired color.
	Croquette	1 piece (3.5 oz. / Approx. 100g)	325	9-11	Required	
	Pork Cutlet	1 piece (7.8 oz. / Approx. 220g)	300	14-17	Required	
	Karaage Chicken	9 pieces (7.9 oz. / Approx. 225g total)		8-9	Required	
	Fried Chicken	2 pieces (1 drumstick 2.1 oz. / Approx. 60g and 1 thigh 4.9 oz. / Approx. 140g)	175	14-16	Required	—
	Toaster Pastry	2 pieces (3.5 oz. / Approx. 100g total)		2-3	—	—
Recipes	Roasted Vegetables	for 1 tray	400	13-16	Required	See pg. 11 for "RECIPES".
	Oatmeal Raisin Cookies	6 cookies	275	9-10	Required	

★: When oven is cold.

- Be careful when toasting thinly sliced bread, or thinly sliced French bread as these foods burn easily and may catch fire.
- Oil coming from fried foods may catch fire, so be careful not to overheat these foods.
- When sliced bread or foods with a high water content are cooked, steam may arise from the gap between the product and the Door or from the holes in the product, but this does not indicate a malfunction.

# RECIPES

## Note

The measurements used in these Recipes:

1 cup = 237mL 1 Tbsp. = 15mL 1 tsp. = 5mL

## Roasted Vegetables

Temperature Setting 400

For 1 tray


Timer approx. 13-16 minutes

Use the Baking Tray

### Ingredients (for 1 tray)

- 1/3 medium zucchini (approx. 2.3 oz.)
- 1/3 medium yellow squash (approx. 2.3 oz.)
- 1/2 medium onion (approx. 1.9 oz.)
- 10 asparagus spears, trimmed (approx. 1/4 lb.)

- A**
- 2 garlic cloves, chopped finely
  - 2 tsp. extra virgin olive oil
  - 1/2 tsp. balsamic vinegar
  - 1/4 tsp. dried basil
  - 1/4 tsp. salt
  - 1/8 tsp. black pepper



### How to Prepare

- 1 Cut the zucchini and yellow squash into 1/4" (approx. 6mm) thick round slices.
- 2 Cut the onion into 1/2" (approx. 1.3cm) thick round slices, and then cut the slices into half circles.
- 3 Cut the asparagus into 1-1/2" (approx. 3.8cm) long pieces.
- 4 Place 1 to 3 in a large bowl, add the ingredients from **A**, and mix together.
- 5 Line Baking Tray with aluminum foil, coat the aluminum foil with a small amount of olive oil (not included in the ingredients list), and arrange 4 evenly on the aluminum foil.
- 6 Set the Temperature Dial to 400, turn the Timer Dial to 13-16 minutes, and roast the vegetables.
  - The vegetables are done cooking when they become soft and have a lightly toasted color.

## Oatmeal Raisin Cookies

Temperature Setting 275

1 Batch of 6 Cookies


Timer approx. 9-10 minutes

Use the Baking Tray

### Ingredients (for 12 cookies)

- 3 Tbsp. unsalted butter
- 2 Tbsp. sugar
- 3 Tbsp. light brown sugar
- 1/2 large egg, beaten
- 1/4 tsp. vanilla extract
- A**
  - 1/3 cup all purpose flour
  - 1/3 tsp. baking soda
  - 1/4 tsp. ground cinnamon
  - A pinch of salt
- 2/3 cup rolled oats
- 1/4 cup raisins

#### •How to Arrange the Cookies



### How to Prepare

- 1 Bring the butter to room temperature. Put **A** in a bowl and mix lightly.
- 2 In another large bowl, mix together the butter, sugar and light brown sugar until smooth. Add the beaten egg and vanilla extract, and stir until soft and light.
- 3 Add and mix the ingredients from **A** to the bowl from step 2 in portions, and then fold in the rolled oats and raisins.
- 4 Prepare two sheets of aluminum foil that are the size of the Baking Tray. (Make sure the aluminum foil does not extend from the Baking Tray.) Line the Baking Tray with one of the aluminum foil, divide the cookie batter into 12 equal portions (approx. 1 Tbsp. each), and arrange six portions on each aluminum foil sheet as shown in the illustration on the left.
- 5 Dust your palm with a small amount of all purpose flour (not included in the ingredients list) and press each portion from above until they are 1/4" (approx. 6mm) thick.
- 6 Set the Temperature Dial to 275, turn the Timer Dial to 9-10 minutes, and bake the cookies.
- 7 When the cookies are done baking, transfer the cookies and aluminum foil together to a cooling rack and allow to cool. Bake the remaining six cookies in the same manner.
  - When the cookies have cooled sufficiently, peel them gently from the aluminum foil.

# CLEANING AND MAINTENANCE

Be sure to unplug the Power Plug from the electrical outlet and allow the product to cool before cleaning.


## IMPORTANT

- Do not use the following:
  - Detergents other than mild kitchen detergent, such as thinner or bleach. Doing so may cause discoloration, cracks, degradation or corrosion.
  - Polishing powder, nylon brushes, scrub brushes, anything made with metal, eraser pads, hard nylon sponges and abrasive cleaners. Doing so may cause corrosion.
- When using chemically treated cloths, do not rub too hard or leave them on the product for a long time as the surface of the product may become damaged from chemical reactions.

● **Do not use a dishwasher or a dish-dryer.**

## Main Body (Exterior and Oven Interior)

- ① Moisten a soft cloth with diluted mild kitchen detergent, firmly wring out the cloth, and wipe away any dust.
- ② Wipe with a soft cloth moistened with water and well-wrung.
- ③ Wipe away any moisture with a dry soft cloth.




## IMPORTANT

- Do not splash water directly onto the product or immerse the product in water. (Doing so may cause electric shock, breakdown or damage to the product.)
- Do not touch the Heaters. (The Heaters may break.)
- Do not press or pull on the Heater Guards.
- Clean the Oven Interior after every use. (Use in an unclean condition may result in uneven cooking or increase the needed cooking times.)

## Door, Baking Tray, Crumb Tray and Rack


### Door, Baking Tray and Crumb Tray

- ① Wash with diluted mild kitchen detergent.
- ② Rinse with water.
- ③ Wipe away any moisture with a dry soft cloth.



### Rack

- ① Wash by immersing in mild kitchen detergent diluted with warm water.
- ② Rinse with water.
- ③ Wipe away any moisture with a dry soft cloth.



## IMPORTANT

- Clean after every use. If the Crumb Tray is not cleaned, food crumbs may stick and become difficult to remove. (Not doing so may burn the tabletop or countertop, or result in uneven cooking on the bottom side of foods, such as the bottom side of bread not toasting as well as it did at the time of purchase.)
- Be careful not to apply strong impact to or otherwise damage the Glass Window. (The glass may break.)
- Handle the Door gently. (Rough handling may cause deformation, breakdown or damage to the product.)
- Remember to securely attach the Door, Crumb Tray and Rack after cleaning.
- After washing, wipe away any moisture and allow them to dry completely before attaching the parts (to prevent water from accumulating).
- Do not clean with hot water (122°F/50°C or hotter). (Doing so may cause deformation, breakdown or damage to the product.)
- Do not soak the removable parts or leave it immersed in water for a long time. (Doing so may cause rust.)

**Power Cord and Power Plug**

Wipe clean with a dry soft cloth.


# HOW TO ATTACH AND REMOVE PARTS

Be sure to unplug the Power Plug from the electrical outlet and allow the product to cool before attaching and removing parts.

## Rack


### How to Remove

- ① Open the Door halfway, pull out the Rack in the direction of the arrow, and disengage it from the Rack Hooks (one on each side).



Rack Hook (left)

- ② Move the Rack gently toward the back of the oven and disengage it from the Rack Support.



Rack Support

#### IMPORTANT

Once the Rack is removed, the Door is no longer supported by the Rack. Please open and close the Door carefully and do not apply strong force to the Door. (Doing so may cause deformation, breakdown or damage to the product.)

### How to Attach

Reverse the removal procedure.


#### IMPORTANT

Be sure to attach the Rack to the Rack Support and the Rack Hooks.

## Door

### How to Remove

- After removing the Rack, open the Door halfway, lift up the Door slightly, and disengage the Door Support Bar from the Main Body Hooks (one on each side).



### How to Attach

Hold the Door and attach the Door Support Bar to the Main Body Hooks (one on each side). (See illustration above.)


#### IMPORTANT

Attach the Door Support Bar securely to the Main Body Hooks.

## Crumb Tray

Pull out toward the front.

The "THIS SIDE UP" mark indicates which side should face up.



#### IMPORTANT

- Clean the Crumb Tray after every use. Do not use it in an unclean condition. (Using in an unclean condition may burn the tabletop or countertop, or result in uneven cooking on the bottom side of foods, such as the bottom side of bread not toasting as well as it did at the time of purchase.)
- The Crumb Tray has a top and bottom. Insert the Crumb Tray so the "THIS SIDE UP" mark is facing up.

# TROUBLESHOOTING GUIDE

Please check the following points before calling for service.

Problems	Cause	Remedy
Food does not cook. (The Heaters do not turn on.)	Is the Power Plug inserted securely into an electrical outlet?	Insert the Power Plug firmly into the electrical outlet.
	Was the Timer Dial set?	Set the Timer Dial.
The Heaters turn off partway through cooking.	This does not indicate a malfunction. This toaster oven has a thermostat that automatically turns the Heaters on and off while cooking. When using consecutively, the thermostat operates and the frequency of the Heaters turning on and off increases or the Heaters may not turn on for a while, so the cooking time may need to be extended.	
The bottom side of bread does not toast well.	This product is pre-set so that the bottom side of bread is toasted slightly lighter than the top side. Thick-sliced bread will be closer to the Heater, and the top side may toast slightly darker.	
	If the Crumb Tray is unclean, the bottom side of bread may not toast as well as it did at the time of purchase.	Clean the Crumb Tray. (See pg. 12)  Clean the Crumb Tray after every use. If not cleaned, food crumbs may stick and become difficult to remove.
Bread toasts unevenly.	Is the bread arranged evenly on the Rack?	Arrange the bread evenly. (See pg. 8)
	The toasted color will vary depending on the size, bread type, thickness, number of slices, and other factors.	

# SPECIFICATIONS

<b>Model No.</b>		ET-WMC22
<b>Electrical Rating</b>		AC 120V 60Hz
<b>Electric Consumption</b>		1000W
<b>Timer</b>		30 minutes
<b>Length of the Power Cord</b>		3'00" (0.9m)
<b>External Dimensions</b>	<b>(approx. inch)</b>	15-3/4 (W) × 11-1/4 (D) × 9-3/8 (H)
	<b>(approx. cm)</b>	40 (W) × 28.5 (D) × 23.5 (H)
<b>Interior Dimensions</b>	<b>(approx. inch)</b>	10-5/8 (W) × 8-5/8 (D) × 3-5/8 (H)
	<b>(approx. cm)</b>	27 (W) × 22 (D) × 9.5 (H)
<b>Weight</b>		Approx. 9 lbs. (3.9kg)

- This product is not suitable for use in countries or regions with different power supply voltages or frequencies.
- This product may not operate properly in certain environments or places with high altitudes or extreme weather conditions. Please avoid using this product in such areas.

# REPLACEMENT PARTS

- Replacement parts may be available for an additional charge. Please replace damaged parts only with new parts.
- When replacing parts, please record the model number and part name beforehand. Parts can be purchased through Zojirushi.com, by contacting Zojirushi Customer Service, or the store where you purchased the product.

## Zojirushi Customer Service

1-800-733-6270      www.zojirushi.com

Parts Names	Parts No.
Baking Tray	BX172031G-00
Rack	BG454028G-00
Crumb Tray	BX172030G-00



[www.zojirushi.com](http://www.zojirushi.com)

ET-WMC ©®