



NEURO FUZZY® RICE COOKER & WARMER **OPERATING INSTRUCTIONS**

NS-DAC10

ZUTTO



INDEX

IMPORTANT SAFEGUARDS	2	HAND-ROLLED SUSHI	17
PARTS NAMES AND FUNCTIONS	6	PAELLA	18
EXPLANATION OF RICE	8	PORRIDGE WITH GREEN TEA	19
TIPS TO COOK TASTY RICE (PREPARATION & KEEP WARM)	9	MINISTRONE WITH RICE	20
BASIC COOKING STEPS	10	CLEANING AND MAINTENANCE	21
TIPS TO COOK TASTY RICE BY MENUS	12	REPLACEMENT PARTS	22
USING THE TIMER	13	TROUBLE SHOOTING GUIDE	23
HOW TO SET THE CLOCK	15	ERROR DISPLAYS AND THEIR MEANINGS	25
SOUND SIGNALS & HOW TO CHANGE IT	16	SPECIFICATIONS	25

BEFORE USE

IMPORTANT SAFEGUARDS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- 1** Read all instructions carefully.
- 2** Do not touch hot surfaces. Use handles or knobs. Do not close or clog the steam vent opening under any circumstance.
- 3** To prevent electrical shock hazards, do not immerse cord, plugs, or rice cooker, except inside pan, in water or any other liquid.
- 4** Close supervision is necessary when the appliance is used by or near children.
- 5** Unplug from outlet when neither the cooker nor warmer is in use, or before cleaning. Allow to cool before putting on or taking off any parts, and before cleaning the appliance. Make sure appliance is OFF when not in use, before putting on or taking off parts, and before cleaning.
- 6** Do not use or operate the appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility or dealer for examination, repair, or adjustment.
- 7** The use of accessories attachments not recommended by the appliance manufacturer may cause hazards.
- 8** Do not use outdoors.
- 9** Do not let the power supply cord hang over the edge of tables or counters, or touch hot surfaces.
- 10** Do not place the appliance on or near heat sources such as hot gas or electric burners and stoves, or in a heated oven.
- 11** Extreme caution must be used when moving the appliance containing hot contents or liquids.
- 12** Plug the cord into a household electric outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- 13** Do not use the appliance for other than intended or specified purposes.
- 14** To reduce the risk of electrical shock, cook only in removable container.

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

This appliance is supplied with a short cord to reduce the risk of becoming entangled or tripping. Extension cords are available and may be used if care is exercised in their use. If extension cord is used, the marked electrical rating of extension cord should be at least as great as the electrical rating of the appliance, and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally. “This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.”

IMPORTANTES MESURES DE SÉCURITÉ

LORS DE L'UTILISATION D'APPAREILS ÉLECTRIQUES, SUIVEZ LES PRÉCAUTIONS DE BASE SUIVANTES :

- 1** Lisez bien toutes les instructions.
- 2** Ne touchez pas les surfaces qui peuvent être chaudes. Utilisez les poignées ou les boutons. N'obturez en aucun cas l'orifice d'échappement de la vapeur.
- 3** Pour éviter les chocs électriques, ne plongez pas le cordon, la fiche ou l'appareil portatif, à l'exception du récipient intérieur, dans de l'eau ou dans un autre liquide.
- 4** Soyez vigilants lorsque les enfants utilisent l'appareil ou se trouvent à proximité.
- 5** Débranchez l'appareil de la prise de courant lorsque vous ne l'utilisez pas ou avant de le nettoyer. Laissez l'appareil refroidir avant de le manipuler ou de le nettoyer. Assurez-vous qu'il est arrêté lorsque vous ne l'utilisez pas, avant d'y enlever ou d'y installer les accessoires ou encore avant de le laver.
- 6** N'utilisez pas l'appareil lorsque le cordon ou la fiche sont endommagés ou lorsque l'appareil est pour une raison quelconque abîmé. Confiez l'appareil au service de réparation recommandé le plus proche pour toute réparation, tout examen ou réglage.
- 7** L'utilisation d'accessoires non conseillés par le fabricant peut entraîner des dégâts.
- 8** N'utilisez pas l'appareil à l'extérieur.
- 9** Ne laissez pas le cordon électrique pendre par-dessus le bord d'une table ou d'un comptoir et assurez-vous qu'il n'est pas en contact avec une surface chaude.
- 10** Ne placez pas l'appareil près d'une surface chaude telle qu'un brûleur à gaz allumé, une plaque électrique, un poêle ou encore dans un four en train de chauffer.
- 11** Soyez très prudent lorsque vous déplacez l'appareil contenant un liquide ou un aliment chaud.
- 12** Branchez le cordon dans une prise domestique. Avant de débrancher l'appareil, placez-le sur la position ARRÊT puis retirez la fiche de la prise murale.
- 13** N'utilisez pas l'appareil pour d'autres fonctions que celles auxquelles il est destiné.
- 14** Pour minimiser les risques de chocs électriques, ne cuire que dans le récipient amovible.

CONSERVEZ CES INSTRUCTIONS

CET APPAREIL EST UNIQUEMENT À USAGE DOMESTIQUE.

L'appareil est livré avec un cordon court afin de réduire les risques d'emmêlements ou de chutes. Des rallonges électriques sont disponibles et peuvent être utilisées en respectant les précautions nécessaires. En cas d'utilisation, la tension du courant indiquée sur la rallonge électrique devra au minimum être égale à celle de l'appareil et la longueur du cordon sera réglée de manière à ce qu'il ne pende pas de la table ou du comptoir où il est posé afin d'éviter les accidents d'emmêlement dans le cordon ou tout accident provoqué par des enfants qui tireraient dessus. Il a une fiche polarisée (l'une des broches étant plus large que l'autre). Pour minimiser les chocs électriques, la fiche s'adapte dans un seul sens à une prise polarisée. Si la fiche n'entre pas correctement dans la prise, retournez-la. Si elle n'entre toujours pas, prenez contact avec un électricien agréé. Ne cherchez jamais à modifier la prise.


BEFORE USE

IMPORTANT SAFEGUARDS


Be sure to follow the instructions.

● These WARNINGS and CAUTIONS are intended to protect you and other persons from injuries and damages. To ensure safe operation, please follow them carefully.


 **WARNINGS** Indicates risk of serious injury. ※1

 **CAUTIONS** Indicates a warning or caution. A specific caution is indicated inside or near the triangle by sentences or illustrations.

 **CAUTIONS** Indicates risk of injury or property damage if mishandled. ※2 ※3

 **PROHIBITIONS** Indicates a prohibition. A specific prohibition is indicated inside or near the circle by sentences or illustrations.

※1 Serious injury indicates loss of eyesight, injury, burn (high and low temperature), electrical shock, bone fracture, toxication and others that may cause aftereffects and require hospitalization or a long period of hospital visit.

 **INSTRUCTIONS** Indicates a requirement or instruction that must be followed. A specific instruction is indicated inside or near the circle by sentences or illustrations.

※2 Injury indicates a physical damage, burn or an electrical shock that may not require hospitalization or a long period of hospital visit.

※3 Property damage indicates material damage towards house, furniture, domestic animal or pets.

WARNINGS



Do not modify the Rice Cooker. Only a repair technician may disassemble or repair this unit.

Attempting to do so may cause fire, electrical shock, or injury. Make any repair inquiries to Zojirushi Customer Service.



Do not immerse the Rice Cooker in water or splash it with water. Do not pour water directly into the Rice Cooker.

Doing so may cause a short-circuit or electrical shock.



Do not plug or unplug the Power Plug with a wet hand.

Doing so may cause an electrical shock or injury.



Do not touch the Steam Vent.

Doing so may cause burns or scalding. Take special precautions with children and infants.



Do not allow children to use the Rice Cooker unsupervised. Keep it out of the reach of infants.

Children are at risk of burns, electrical shock or injury.



Do not put any metal objects such as pins or wires into the holes located at the bottom of the Rice Cooker.

Doing so may cause an electrical shock or malfunction, resulting in injury.



Do not use the Rice Cooker if the Power Plug or Power Cord is damaged or a plug is loosely inserted into the Electrical Outlet.

Doing so may cause an electrical shock, short-circuit or fire.



Do not damage the Power Cord.

Do not forcefully bend, pull, twist, fold, bring it near high temperature objects, place heavy items, sandwich it between other objects or modify it. A damaged Power Cord can cause a fire or electrical shock.



Do not touch the Hook Button of the Rice Cooker while cooking or carrying.

The Outer Lid may open, resulting in burns.



Use only an electrical outlet rated at 15 amperes minimum. Do not plug other devices into the same outlet.

Plugging other devices into the same outlet may cause the electrical outlet to overheat, resulting in fire.



Do not use a power source other than 120V AC.

Use of any other power supply voltage may cause a fire or electrical shock.



Insert the Power Plug securely.














Otherwise it may cause an electrical shock, short-circuit, smoke or fire.



If the blades or surface of the Power Plug are soiled, wipe them clean.

A dirty Power Plug may cause a fire.

⚠ CAUTIONS

<p> Do not touch hot surfaces during or immediately after use. Be careful of steam when opening the Outer Lid. Be careful not to touch the Inner Cooking Pan when loosening rice.</p> <p>Touching hot surfaces may cause burns.</p> <p>Be careful especially with metal parts such as the Inner Lid and the Inner Cooking Pan.</p> 	<p> Do not touch the Hook Button when moving the Rice Cooker.</p> <p>Doing so may cause the Outer Lid to open, resulting in injury or burns.</p> 
<p> Do not use the Rice Cooker where it may be splashed with water or near heat sources.</p> <p>Doing so may cause an electrical shock, short-circuit, or deformation of the Rice Cooker.</p>	<p> Do not use other than the provided Inner Cooking Pan.</p> <p>Doing so may cause the Inner Cooking Pan to overheat and may cause the Rice Cooker to malfunction.</p>
<p> Do not use the Rice Cooker near a wall or furniture. Make sure that steam does not collect under shelvings.</p> <p>Steam or heat may damage, discolor or deform the wall or furniture.</p>	<p> Do not place or use the Rice Cooker on unstable surfaces or on surfaces that are vulnerable to heat.</p> <p>Doing so may cause fire.</p>
<p> Please allow the Rice Cooker to cool down before cleaning.</p> <p>Touching hot parts may cause burns.</p>	<p> Unplug the Power Plug from the outlet when the Rice Cooker is not in use.</p> <p>Leaving the Power Plug in an outlet may cause the insulation to become damaged, resulting in an electrical shock, short-circuit or fire.</p>
<p> Be sure to hold the Power Plug when unplugging the Power Cord. Do not unplug pulling the Power Cord.</p> <p>Pulling the Power Cord to unplug may cause an electrical shock, short-circuit or fire.</p>	<p> Always retract the Power Cord holding the Power Plug.</p> <p>Being struck by the Power Plug may result in injury.</p>
<p> Do not attempt to disassemble or repair the Power Cord by yourself when damaged.</p> <p>Please check the Model Number of your product and consult with the store you purchased it or contact Zojirushi Customer Service.</p>	

IMPORTANT

<p>■ Do not cover the Steam Vent with a cloth or other objects.</p> <p>Doing so may cause deformation and/or discoloration.</p>	<p>■ Do not cook rice if foreign matters (rice and others) are adhered to the heating plate or the outside of the Inner Cooking Pan.</p> <p>It may cause imperfect cooking.</p>
<p>■ Do not place any objects that might damage the Inner Cooking Pan.</p> <p>A damaged Inner Cooking Pan may not cook the rice well.</p>	<p>■ Do not use the Rice Cooker as a steamer or other purpose than cooking rice or keeping it warm.</p> <p>The Steam Vent may become clogged.</p>

PARTS NAMES AND FUNCTIONS

Main Body


Steam Vent

- Be careful while cooking as steam comes out and is very hot.

Hook Button

Press "☐" gently when opening the Outer Lid.

- The Outer Lid may not open smoothly when the Inner Cooking Pan is not placed inside. If this happens, gently and slowly press down the Hook Button to open.



How to Take the Power Cord Out:

Hold the Power Plug and pull it out. (Do not pull it out beyond the red mark on the cord.)

How to Store the Power Cord:

Hold the Power Plug and pull it out about an inch and let go to automatically retract.

Inner Lid


Inner Lid Knobs (Located at 2 positions: right & left edge)

Use these knobs when attaching and removing the Inner Lid.

- Be sure to attach it after every cleaning.

Inner Lid Gasket

Inner Cooking Pan



Steam Vent

Steam Vent Cap

- Be sure to attach it after every cleaning.

Marking in Japanese, "奥に合わす" means "set till the very end". This tells you to insert the bottom edge of the Inner Lid till the very end as arrow illustration when attaching it to the Outer Lid.

Center Sensor


Heating Plate

Control Panel

- Press keys down firmly.
- The raised dot and dash (●, —) beside the COOKING and RESET keys and the Sound Signals are provided for the use of persons with visual impairments.

Display

The illustration below shows all possible displays as a reference only, and they will not appear during actual use.




Accessories

Spatula



Measuring Cup




Spatula Holder



EXPLANATION OF RICE

Types of Rice

- The name of rice changes depending on the way it is polished and/or processed.



TIPS TO COOK TASTY RICE

(PREPARATION
& KEEP WARM)

How to Cook Tasty Rice

Measure rice accurately

Be sure to use the Measuring Cup provided and level rice off. Do not use other measuring cups as their measurements may vary.

Rinse rice quickly

The first rinse should be done quickly with plenty of water, then dispose the water immediately afterwards. Then change the water and rinse the rice 4 - 5 times to clean out the bran.

Adjust the amount of water accurately

Type of Rice	Water Adjustment
Softer rice White rice with germ	Normal scale level
New crop	Decrease a little from the normal level
Old crop Harder rice	Increase a little from the normal level


Do not use strong alkaline ionic water for cooking rice.

Rice cooked with strong alkaline ionic water may appear yellow or become too glutinous.

Stir and loosen the rice immediately after cooking is complete.

Excessive moisture is released and provides fluffy and perfectly cooked rice.

e.g. When Cooking 3
Cups of White Rice




Add water up to scale 3 of White Rice.

How to Keep Warm

Do not use the Keep Warm mode for the following:

- Re-heating cold rice.
- Keeping rice containing seasonings (Mixed Rice) warm.
- Keeping food other than rice such as croquette or Miso soup warm.
- Keeping rice warm for more than 12 hours.
- Keeping rice warm with the Spatula left inside the cooker.
- Leaving the Rice Cooker unplugged.



For keeping a small amount of rice warm, be sure to gather the rice toward the center of the Inner Cooking Pan to prevent drying.


HOW TO COOK RICE

BASIC COOKING STEPS

1

Measure the rice with the provided Measuring Cup.

A leveled 1 cup of rice in the provided Measuring Cup is approx. 180mL.



2

Rinse the rice and adjust the amount of water.

Place the Inner Cooking Pan on a flat surface and level scales according to the menu you have chosen (refer to the Page 12 "TIPS TO COOK TASTY RICE BY MENUS"), and then flatten the surface of rice.

- You could start cooking rice immediately after rinsing, and it does not need to be soaked. If you soak the rice for a while after water measurement, the texture of the rice may become a little soft.



3

Place the Inner Cooking Pan into the Main Body, close the Outer Lid and plug in the Power Plug.

Wipe off moisture or foreign objects on the outer surface of the pan, then place the pan securely into the cooker.

Be sure to attach the Steam Vent Cap and the Inner Lid.

- If you press the COOKING key without placing the Inner Cooking Pan, a beep will sound and the display will show the error message "H04".

4

Select the desired Menu by pressing the "MENU" key.

- Each press of the key changes the position of the "█" on the display.
- Press and hold the key to fast forward the selection. (It will stop when the selection reaches WHITE RICE / SUSHI)
- QUICK COOKING menu: Choose this menu when cooking White Rice in a hurry. The cooking result of the rice texture may be a little harder.

The remaining time till completion in minutes will appear.



5

Press the "COOKING" key.

The Cooking lamp will turn on and the beep / melody to start cooking will sound. When the cooker reaches the steaming process, the display shows the remaining time till completion.

The remaining time till completion in minutes.



COOKING lamp

6

When the beep / melody to indicate completion sounds, stir and loosen the rice immediately for fluffy rice.

The cooker automatically switches to Keep Warm upon completion and the KEEP WARM lamp turns on. The display will show the elapsed time of Keep Warm in hour(s).

- If you wish to know the current time during Keep Warm, press ▲ or ▼ key for time setting. Then press ▲ or ▼ key for time setting to return to the Keep Warm mode. If you do not return the display mode to show the elapsed time of Keep Warm, the display will not show it again at the next cooking. The change of the display modes can only be done during the Keep Warm mode.
- If you cancel the Keep Warm and press the KEEP WARM key again, the display shows 0h.
- The Sound Signal can be changed. Refer to page 16 "SOUND SIGNALS & HOW TO CHANGE IT" for details.

Elapsed time of the Keep Warm function.



7

After use, press "⊗" key, then unplug the Power Plug.

Estimated cooking time from start to completion.

Menus	Required Time	Menus	Required Time
White Rice / Sushi Rice:	45-60 minutes	Mixed Rice:	50-65 minutes
Quick Cooking:	36-45 minutes	Porridge:	55-75 minutes

The above table is based on the testing conditions of 120 Voltage, a room temperature of 68°F (20°C), and water at a starting temperature of 64.4°F (18°C). Please note that the actual time may vary depending on the voltage, room temperature, season, and the amount of water used. The preheat process of the Mixed Rice menu (approx. 30 minutes) allows the rice to absorb the seasonings, and is longer than that of the White Rice menu.

Please Follow:

- Do not open the Outer Lid during cooking to prevent imperfect cooking results.
- When cooking rice consecutively, allow the Main Body and the Outer Lid to cool down to body temperature; otherwise it will not cook well.
- To prevent breakdown, do not press the COOKING key when the Inner Cooking Pan is empty.
- Depending on the cooking condition, the bottom of the rice may become slightly browned.
- The center of the rice may be caved in due to the cooking mechanism of surround heating.

HOW TO USE

HOW TO COOK RICE (cont.)

TIPS TO COOK TASTY RICE BY MENUS

- When measuring rice, use the Measuring Cup provided and level off.

MIXED RICE:

Amount of Rice:	For best results, cook less than 4 cups; otherwise the cooking results may not be satisfactory.
Water Level:	Use the water level for WHITE RICE .
Menu Selection:	Select the MIXED menu.
Ingredients:	The appropriate amount of ingredients should be about 30-50% of the rice volume (weight). Excessive amount of rice may not cook properly. (1 cup of rice is about 5.3oz.) Chop the ingredients into small pieces and put them on top of the rice without mixing them into the rice.
Remarks:	Seasonings should be mixed with soup stock or water and then added to the rice. After adjusting the amount of water, stir it well from the bottom of the Inner Cooking Pan. If the seasonings are added directly to the rice or if not mixed properly, scorching or imperfect cooking may occur.

SUSHI RICE:

Water Level:	Use the water level for SUSHI RICE .
Menu Selection:	Select the WHITE RICE / SUSHI menu.

RICE MIXED WITH BARLEY:

Water Level:	Slightly more water than the water for WHITE RICE .
Menu Selection:	Select the MIXED menu.
Remarks:	The amount of barley mixed into the rice should be less than 20% of the total volume; otherwise it may not cook properly. e.g. Cooking 1 cup of Rice mixed with Barley, use 0.8 cup of White Rice and 0.2 cup of Barley.

PORRIDGE:

Rice Type:	Semi-brown rice (30%, 50%, and 70%) or Brown Rice can not be used.
Water Level:	Use the water level for PORRIDGE .
Menu Selection:	Select the PORRIDGE menu.
Ingredients:	The appropriate amount of ingredients should be about 30-50% of the rice volume (weight). Chop the ingredients into small pieces and put on top of rice without mixing them into the rice. Ingredients which do not cook easily should not be used in large amounts. Boil green leaf vegetables separately and add them after the rice porridge is finished cooking.

QUICK COOKING:

Water Level:	Use the water level for WHITE RICE .
Menu Selection:	Select the QUICK COOKING menu.
Remarks:	Choose this menu when you want to cook rice in a hurry. The rice may be slightly harder than normal.

USING THE TIMER

- This function makes the Rice Cooker automatically complete cooking at your desired time.


e.g. When you wish the rice to complete cooking at 7:30.

- Be sure to check if the current time is correct before setting the Timer function.
→ P.15

1

Press "  " to show the Timer setting on the display.

The display shows the preset time of 6:00 and the displayed time and the COOKING lamp will blink.




2

Press "  " to select the desired Menu.

- The Timer function is not available for Quick Cooking and Brown Rice menus.


3

Press "  " or "  " key for time setting to set the desired time to complete cooking.

 key: Each press advances in increments by 10 minutes.

 key: Each press moves time backwards by 10 minutes.

- Press and hold the key to fast forward by 10 minutes.




4

Press the "  " key.

The COOKING lamp will turn off and the set time of 7:30 will be displayed and the TIMER lamp will turn on with a beep sound.

- The COOKING key must be pressed to set the Timer.



NOTE:

- To cancel the Timer setting, press the RESET key.
- If you wish to know the current time during the Timer mode, press "  " or "  " key for time setting.


USING THE TIMER (cont.)

To use the stored Timer settings


- Once the Timer is set, the settings are stored in the Rice Cooker. You do not need to set the time again when using the same setting.

1 Press "  " to show the Timer setting on the display.


The display shows the preset time of 7:30 and the displayed time and the COOKING lamp will blink.



The Timer illustration appears


2 Press "  " to select the desired Menu.

- The Timer function is not available for Quick Cooking and Mixed Rice menu.

3 Press the "  " key.

- The TIMER setting is activated and a beep / melody will sound.

The time you wish to complete cooking.



Turns on

Goes off

Suggested lengths for the Timer setting:

Menus	Timer Setting
White Rice / Sushi Rice	1 hour—13 hours
Porridge	1 hour 15 minutes—13 hours

NOTE:

- The rice may cook a little softer in texture when the Timer function is used.
- The remaining time till cooking completion will not show when the Timer is set.
- If the Timer is set shorter than the above suggested timing, a beep will sound and it will start cooking immediately.
- Be sure to set the Timer shorter than 13 hours especially during summer to prevent the soaked rice from spoiling due to the high room temperature.

HOW TO SET THE CLOCK

It is important to first set the clock when cooking rice using the Timer. Although the clock is set before shipment from the factory, certain conditions such as fluctuating temperatures may cause it to display inaccurate time.

If the clock is not accurate, set the correct time as shown below.

e.g. If the current time is 15:01 but displays 14:58.

1 Set the Inner Cooking Pan and plug in the Power Plug.


2 Press "▲" key for time setting and adjust the clock to the current time.

The time display will start to blink.

- ▲ key: Each press advances in increments by 1 minute.
- ▼ key: Each press moves time backwards by 1 minute.

- Press and hold the key to fast forward by 10 minutes.

Adjusting the time



- It will return to original after 5 seconds.

3 When the time display stops blinking, the time adjustment is completed.

After the time setting is completed, the time will stop blinking after 3 seconds.

Time correction is completed



HOW TO USE

SOUND SIGNALS & HOW TO CHANGE IT

This product is equipped with sound signals, which will inform you when the Rice Cooker starts cooking, the Timer is set or cooking is completed by sounds.

The sound signals can be changed from a beep to a melody, or disabled (when notifying completion of cooking).

Types of Sound Signals:

※Silent Function will disable the Sound Signal only when cooking is completed. A beep will still sound to notify when cooking is started and the Timer is set.

Types of Sound Signals and their meanings	Beep:	Melody:	Silent:※
Indication	The default setting at the time of purchase.	Choose this setting if you wish to change from Beep.	Choose this setting if you wish to disable the Sound Signal when cooking is completed.
Cooking is Started:	a beep	"Twinkle, Twinkle, Little Star"	a beep
Timer is Set:	a beep	"Twinkle, Twinkle, Little Star"	a beep
Cooking is Completed:	beeps 5 times	"Amaryllis"	no sound

How to change the Sound Signal:

1 Set the Inner Cooking Pan and plug in the Power Plug.


2 Hold "⏸" key for more than 3 seconds.

3 The setting is completed when the desired Sound Signal is heard.

- You can not change the sound during Cooking or Keep Warm.
- If you find it difficult to change / select the sound, please retry from procedure 1.

When changing the Sound Signal:

- Each time the Timer key is held for more than 3 seconds, the Sound Signal will change.



RECIPES

The measurements used in these Recipes:

- Be sure to measure the rice with the Measuring Cup provided. (1 Cup = approx. 180mL)
- Table Spoon = 15mL
- Tea Spoon = 5mL

HAND-ROLLED SUSHI

Menu Selection : Select the **WHITE RICE / SUSHI** menu.



Ingredients (4~5 servings)

Rice	3 cups
Mixed vinegar	
{ Vinegar	4 Tbsp.
{ Sugar	1 Tbsp.
{ Salt	1-1/2 tsp.

Ingredients (suggested)

{ Sashimi (tuna, squid, prawn, etc.)
{ Pickles (e.g. pickled radish)
{ Natto (fermented soy bean) and beefsteak plant leaf
{ Avocado and ham
{ Sea eel, rolled egg and cucumber

Seaweed, wasabi (horse radish), soy sauce and pickled red ginger.....To taste

How to cook

- 1 Rinse the rice and put it in the Inner Cooking Pan, add water until the water level reaches 3 for SUSHI measurement.
 - 2 Press the "MENU" key, select "WHITE RICE / SUSHI" and press the "COOKING" key to start cooking.
 - 3 When cooking is completed and the Rice Cooker switches to Keep Warm mode, move the rice to a wooden container, wiped and moisturized with a clean wet cloth. Pour the mixed vinegar on the rice and mix it while cooking it with a fan.
- Hand-rolled sushi is a type of sushi that is made by each individual by rolling his/her favorite ingredients in sushi rice and seaweed. The seaweed may be replaced with green leaves.



Ingredients (4~5 servings)

Rice.....	3 cups	Olive oil.....	2 Tbsp.	
Prawns.....	4~6 pieces	Salt.....	1/2 tsp.	
Hard clams (mull clams, if available).....	4~6 pieces	A {	Soup stock (cube).....	1 cube
Squid.....	5.3 oz.		Saffron.....	1/2 tsp.
Green peppers.....	3 pieces		(Tumeric can be substituted.....)	1/2 tsp.)

How to cook

- 1 Peel the shells off the prawns and remove the entrails. Remove sand from the clams and wash. Cut squid into small pieces. Cut green peppers into small cubes.
- 2 Stir-fry ingredients from Step 1 with olive oil. Season with salt and cover with a lid until the clamshells open up. Put the ingredients and 2 Tbsp. of the broth aside.
- 3 Finely chop the soup stock cubes.
- 4 Rinse rice and put it in the Inner Cooking Pan then add water until it covers the rice. Put "A" into the pan and add more water until the water level reaches 3 for WHITE RICE measurement. Mix it well from the bottom of the pan.
- 5 Press the "MENU" key, select "MIXED" and press the "COOKING" key to start cooking.
- 6 Upon completion of cooking and when the cooker has switched to the "KEEP-WARM" mode, open the Outer Lid, add the ingredients from Step 2 along with 2 Tbsp. of the broth and mix well with the rice.

PORRIDGE WITH GREEN TEA

Menu Selection : Select the **PORRIDGE** menu.



Ingredients (3 servings)

Rice	1 cup
Green tea bags (Sencha recommended)	
	2 bags (approx. 0.2 oz.)
Salt	To taste

How to cook

- 1 Rinse rice and put it in the Inner Cooking Pan. Add water until the water level reaches 1 for "PORRIDGE" measurement. Add the Sencha tea bags.
 - 2 Press the "MENU" key, select "PORRIDGE" and press the "COOKING" key to start cooking.
 - 3 When cooking is completed and the Rice Cooker switches to Keep Warm mode, take the tea bags out and add salt to taste.
- You can make your own tea bags with other teas such as Bancha. In that case, put 1/3 Tbsp. of the tea leaves in a tea bag and follow the same directions.

MINISTRONE WITH RICE

Menu Selection : Select the **PORRIDGE** menu.



Ingredients (4~5 servings)

Ingredients

Potato	1.8 oz.	Rice	2 Tbsp.
Carrot	1.8 oz.	Soup stock (cube)	2 cubes
Onion	3.5 oz.	Salt, Pepper	To taste
Celery	0.7 oz.	Parsley (finely chopped)	To taste
Tomato	1.6 oz.		
Bacon	1.4 oz.		

How to cook

- 1 Slice ingredients thinly into small pieces. Rinse rice and add the finely chopped soup stock cubes.
- 2 Put 1 in the Inner Cooking Pan and add water until the water level reaches 1.5 for PORRIDGE measurement. Stir it well from the bottom of the pan.
- 3 Press the "MENU" key, select "PORRIDGE" and press the "COOKING" key to start cooking.
- 4 When cooking is completed and the Rice Cooker switches to Keep Warm mode, add salt to taste.
- 5 Serve in a bowl and sprinkle Parsley over it.

CLEANING AND MAINTENANCE

- Be sure to unplug the Power Plug and allow the Main Body and the Inner Cooking Pan to cool down.
- Do not use a thinner, benzene, abrasive cleaners and brushes (nylon / metal), bleach or anything that may damage the surface of the cooker.

How to Clean the Exterior

Exterior:

Clean it with a cloth soaked in a kitchen detergent and wrung well. Wipe the Control Panel clean with a dry and soft cloth.



Power Cord

Power Plug

Wipe with a dry damp cloth.


- When using a chemically treated cloth, do not scrub the Rice Cooker hard or allow the cloth to contact the Rice Cooker for an extended time.

How to Remove and Attach the Inner Lid

How to remove the Inner Lid:

Pull the Inner Lid Knobs toward you.


Inner Lid Knobs



How to attach the Inner Lid:

- ① Insert the fixtures found on both sides at the bottom of the Inner Lid into the Outer Lid.
- ② Then lift the Inner Lid up toward the Outer Lid.
- ③ Press the bottom of the Inner Lid in the direction of the arrow shown in the illustration to secure in place.

The fixtures of the Inner Lid




How to Remove and Attach the Steam Vent Cap

How to remove the Steam Vent Cap:

- ① Be sure that the inside of the Outer Lid is cooled down.
- ② Hold the edge of the Steam Vent Cap as illustrated and pull it towards you to remove.


The edge of the Steam Vent Cap



How to attach the Steam Vent Cap:

- ① Insert the Steam Vent Cap to the inside of the Outer Lid.
 - ② Be sure to press in until it is firmly in place.
- If you forget to attach it, the Rice Cooker may overflow or Keep Warm may be unsatisfactory.

Steam Vent



CLEANING AND MAINTENANCE (cont.) REPLACEMENT PARTS

How to Clean the Interior

Inner Lid

Inner Lid Gasket


Soak the Inner Lid in warm or cold water and wash it with a sponge. If it is clogged with rice or foreign matters, remove them using a tooth pick.

- Inner Lid Gasket can not be removed.

Center Sensor

Heating Plate

Wipe the surface clean with a well-wrung cloth. (If rice or any objects are stuck to the Heating Plate, lightly polish them off with sand paper of about No.320 after dipping in water.) Remove the clogged rice grain and foreign matters with a bamboo spatula or a chopstick.



Outer Lid

Hold the Outer Lid securely and wipe it with a well-wrung cloth. Remove the residue and rice attached to the inside of the Outer Lid completely.


Steam Vent Cap

Remove it from the Outer Lid then wash it with running water after every use. Attach it back after wiping it off.

How to Clean the Spatula, Spatula Holder and the Inner Cooking Pan

Wash them with a soft sponge. To wash them thoroughly, use a kitchen detergent.

NOTE: The nonstick coating can peel off if damaged. Please take special care to prevent damages and follow these precautions:



- Do not place spoons or bowls into the Inner Cooking Pan when washing dishes.
- Do not use an abrasive cleaner or brush when cleaning it.
- Do not pour vinegar in the Inner Cooking Pan.
- Clean the Inner Cooking Pan immediately after using any seasonings.

Remarks: The nonstick coating may wear out with use. The nonstick coating may discolor or peel off, but it will not affect its performance or sanitary properties, and is harmless.

REPLACEMENT PARTS

- Please replace damaged parts for optimum performance.
- When replacing parts, please check the model number and the parts name beforehand, then contact the store you purchased the Rice Cooker or Zojirushi Customer Service.

Parts Names	Parts Number
Inner Lid	C99
Inner Cooking Pan	B244
Spatula	8-NSZ-P290

TROUBLE SHOOTING GUIDE







- Please check the following points before calling for service.

Problems	● Cause (Points to check)
Cooking Rice is cooked too hard or too soft.:	<ul style="list-style-type: none"> ● If the rice is cooked on a tilted surface, the texture of the rice may vary as the amount of water becomes too much or too little. ● The texture of rice varies depending on the brand of the rice, where it was harvested, and how long it was stored (new crop or old crop). ● The texture of rice varies depending on the room and water temperatures. ● Using the Timer may result in softer rice. ● Using the Quick Cooking menu may result in harder rice. ● The Inner Cooking Pan may be deformed.
Rice is scorched.:	<ul style="list-style-type: none"> ● Rice grain or foreign objects may be adhered to the Heating Plate, Center Sensor, or to the outside of the Inner Cooking Pan. ● Rice may not have been rinsed sufficiently and too much bran may be left. ● The Inner Cooking Pan may be deformed.
Boiling over while cooking.:	<ul style="list-style-type: none"> ● Is another menu other than PORRIDGE selected when cooking porridge? ● Did you remember to set the Steam Vent Cap or the Inner Lid? ● Rice may not have been rinsed sufficiently and too much bran may be left. ● The Inner Cooking Pan may be deformed.
Not able to cook or keys do not operate.:	<ul style="list-style-type: none"> ● Did you plug in the Power Plug? ● Does the display show "E01" or "E02"? → go to P25 ● Is the Keep Warm lamp turned on? → Press the RESET key and then press the COOKING key again.
Steam comes out from the gap between the Outer Lid and the Main Body.:	<ul style="list-style-type: none"> ● Please check if the Inner Lid is deformed or the Inner Lid Gasket is damaged.

TROUBLE SHOOTING GUIDE (cont.)

Problems	● Cause (Points to check)
<p>KEEP WARM</p> <p>During Keep Warm, rice has an odor, becomes yellow, becomes too dry or there is excessive condensation.:</p>	<ul style="list-style-type: none"> ● Was the rice kept warm for more than 12 hours? ● Was a small amount of rice kept warm? ● Was the rice kept warm with the spatula left in the pan? ● Was cold rice reheated? ● Did you loosen the rice after cooking was completed? → Loosen the rice immediately after cooking is completed. ● Rice may not have been rinsed sufficiently and too much bran may be left. ● The type of rice and water used may make the rice appear yellow. ● After cooking Mixed Rice, some odors can remain. → Clean the Inner Cooking Pan thoroughly.
<p>TIMER COOKING</p> <p>The Rice Cooker starts cooking immediately after the Timer is set.:</p>	<ul style="list-style-type: none"> ● Is the current time set correctly? → The clock shows in 24 hours. Please check it again. ● If the Timer is set at a shorter time than the suggested time, it will start cooking immediately.
<p>The rice is not ready at the set time.:</p>	<ul style="list-style-type: none"> ● Is the current time set correctly? → The clock shows in 24 hours. Please check it again.
<p>The Timer can not be set.:</p>	<ul style="list-style-type: none"> ● Did you press the COOKING key after setting the time? → You need to press the COOKING key to complete setting the Timer.
<p>OTHERS</p> <p>When power failure occurs.:</p>	<ul style="list-style-type: none"> ● If too many appliances are used at the same time, overload may occur and the breaker will cut off the electric supply. → Please do not use the outlet for the Rice Cooker simultaneously with another appliance. If the electric supply recovers within 10 minutes, the cooker will resume cooking.

ERROR DISPLAYS AND THEIR MEANINGS

Panel Display		● Cause (Points to check)
Error Display	 	●Indicates malfunction. → Please contact the store you purchased this Rice Cooker or Zojirushi Customer Service.
	 	●Open the Outer Lid for about 15 minutes and allow it to cool down. (Be careful for scalding).
		●The Inner Cooking Pan is not placed. → Set the Inner Cooking Pan securely.
	Nothing shows on Display:  is blinking:	●The stored Lithium Battery is out. If the Power Plug is unplugged, the display and the stored memories (current time, menu and Keep Warm setting) will be erased. But you could use it as per normal if the clock is set at a correct time. For changing the Lithium Battery, please contact Zojirushi Customer Service for a replacement (with charge).
	Strange display	●Unplug the Power Plug and plug it in again. → The display will show a blinking 7:00. Please reset the time.

SPECIFICATIONS

Model No.		NS-DAC10	
Cooking Capacity [cups]	White Rice, QUICK COOKING	0.18~1.0L	[1~5.5]
	Mixed Rice	0.18~0.72L	[1~4]
	Sushi Rice	0.18~1.0L	[1~5.5]
	Porridge	0.09~0.27L	[0.5~1.5]
Rating	AC 120V 680W		
Average Power Consumption during Keep Warm	37W		
Rice Cooking System	Direct Heating		
The Length of the Power Cord	1.1m (3.6 feet)		
External Dimensions (approx. inch)	9.5(W)x13(D)x 7.5(H)		
Weight	approx. 3.4kg (7.5 lbs)		

- The average power consumption during Keep Warm is the value for maximum rice cooking capacity at a room temperature of 68°F (20°C).
- This product may not operate properly at certain places such as high mountain areas and severely cold areas. Please avoid using this product in such areas.