



Household Use Only

STAINLESS MUG

Model No. **SM-AFE** Instruction Manual

Please read before use. Keep the instructions for future references.

How to Use

- Before use, rinse the Lid Set and the interior of the Mug thoroughly with luke warm water. To avoid leakage, make sure the Seal Rubber is attached properly.
- Check your Mug to ensure no leakage by turning it upside down with the Lid Set attached.

1 Remove the Lid Set from the Mug turning it counter-clockwise.


- Be sure to remove the Lid Set and not only the Lid Cover.

2 Fill up the Mug with drinks and close the Lid Set securely.

- Do not tilt the Mug suddenly when drinking. (The beverage may spill and cause scalding or stain clothes.)
- Close the Lid Set securely.

Preheat or precool the mug before filling with your beverage for better heat retention.

Filling up the Mug with too much drink may cause leakage. If this happens, discard some amount of drinks and close the Lid Set.
NOTE: See next page "Drink Level" for further details.



SM-AFE (E/K/T/C) / D

Please follow the instructions

(This product is for keeping beverages hot or cold.
Do not use for other purposes.)


Please follow the following instructions to avoid scalding, deterioration and discoloration of drinks, as well as malfunction and staining of the product.

Do not allow infants or small children to use this product. Keep out of the reach of infants and small children.

Mishandling may cause injury or scalding.

Keep the drink level as shown in the illustration below.

Fill up the product about 1cm below the rim (part A.)



Be careful not to over fill the Mug. Over filling may cause leakage.

Always use with the Seal Rubber attached.

Usage without the Seal Rubber may cause leaking and/or scalding.

Do not bring the Mug near heat sources such as gas heaters or cooking stoves.

Doing so may cause deformation or discoloration of the product.

Do not shake the Mug when it contains hot beverages.

Doing so may cause scalds or injuries.

Do not disassemble the Mug.

Be careful not to scald yourself when the product contains hot beverages.

Due to the high level thermal efficiency, the exterior of the product will not be hot even if the product contains hot beverages.

Do not use while driving.

May cause scalds and may also stain the interior of the car or your clothes. Attempting to use while driving the car may cause serious accidents.

Do not microwave the Mug.

It may cause sparks and be dangerous. It may also cause its deformation and discoloration.

Always close the Lid securely.

Hot drinks may leak and cause scalding.

Do not use the product if the thermal insulation is lost.

The outside of the product may become hot and cause scalds if it is filled with hot beverages.

Do not remove the sticker on the bottom of the Mug.

Doing so may cause rust or holes.

When using the drink holder of the vehicle:

① **Check if the strength of the holder is sufficient to hold the Mug before use.**

If it is not sufficient, the holder may come off or break and tip the Mug over resulting in scalding, stains on car interior or on clothing.

② **When using a portable drink holder, do not use a hanging-type holder.**

Do not use a holder that is hung from the window or from the air conditioner as the drink holder may slip off.

● Depending on the type of the drink holders, the Mug may not fit in.

Clean the Mug after every use.

Not doing so may cause the Mug to rust or create pinholes in it, or cause beverages to spoil.

When filling the Mug with sports drinks:

- Rinse the inside of the Mug as soon as possible after consumption to prevent rust and/or pinholes.
- Clean the inside using a soft sponge to protect the nonstick coating from being scratched.

● The illustration used in this Instruction Manual and the actual product may vary.

Please follow the instructions

(This product is for keeping beverages hot or cold.
Do not use for other purposes.)

Please follow the following instructions to avoid scalding, deterioration and discoloration of drinks, as well as malfunction and staining of the product.

Finish the drink within the day.

Leaving drinks for a long period of time may cause the drinks to spoil, create gas which increases inner pressure and the Lid may pop off or drinks may splash out causing scalds and injury.

Do not fill the Mug with the following:

- Dry ice and carbonated drinks: contents may spill out or the pressure may cause the Lid Set to burst, causing injuries.
- Liquids containing salt such as soup or Kobo-cha: although the liner is made of 18/8 stainless steel and is nonstick coated, salt may cause rust resulting in loss of thermal insulation.
- Dairy products and fruit juice: if left inside for a long period of time, contents may spoil and produce gas that may cause the Lid Set to burst, causing injuries.
- Fruit pulp and tea leaves: may become caught on the Lid Set and cause contents to spill.

Warning & Caution

Do not touch the mouth of the Mug with the spout of a hot kettle.

The Mug may tilt over causing scalds.

After washing the Lid Set, shake a few times to release the water contained, and wipe it dry.

Otherwise the remaining water may drip out.

To avoid bags getting wet, always place the Mug in an upright position.

Do not close the Lid Set with a teabag is inside.

The teabag may swell and cause leakage or may cause drinks to splash out.

Do not attach parts other than those specifically for this product.

Doing so may cause leaks or breakage.

Do not drop or apply strong shocks to the product.

May cause plastic parts to break and dent the stainless steel exterior.

Do not scratch the printing on the Mug with hard elements.

It may come off.

Do not attempt to put large ice cubes into the Mug. Crush ice into small pieces.

It may cause deformation or damage.

Clean the Lid Set and the Seal Rubber after every use.

Not doing so may cause decay, mold, odor or discoloration. It may also cause leaks.

Be careful not to close the Lid Set while the tealeaves or the string of the teabag is stuck at the Seal Rubber. It may cause leakage and resulting in scalding.

Keeping hot tea warm for long hours may cause the color of the tea to change. It is recommended to use the Compartment of the Mug to bring tealeaves with you for fresh brewing.

The rattling noise that may be heard when the product is shaken comes from the copper or aluminum foil in the vacuum insulation to increase heat retention and does not indicate a malfunction.

Cleaning

Always clean the mug after use.

- For better usage, please remember to clean after every use.

The Exterior and Lid Set (Lid, Lid Cover, Seal Rubber)

Wash with warm water and mild dishwashing liquid using a soft sponge. Rinse well and dry with a soft cloth.

- When cleaning the Lid Set, be sure to disassemble it first (see next page for details).
- Be sure to assemble the Lid Set correctly after each cleaning to prevent leaks.
- Storing tea may stain the Lid Set. Although the stain may not come out completely, it will not effect the performance or use of the product.

The Inside

Use a brush with handle to clean with warm water and mild dishwashing liquid, rinse and dry. Always wash the inside thoroughly after each use to prevent odors from developing.

- Wipe off moisture thoroughly to prevent water stains or rusting of the product.
- Do not soak for an extended period of time.
- Do not use chlorine type bleach.
- Do not clean with thinner, benzene, abrasive cleaners or other harsh cleaners.
- Do not use a dishwasher or dish-dryer. Do not boil to sanitize.

To Remove Rust Spots and Water Stains:

You may find rust spots or water stains caused by impurities in the water. To remove these stains, fill the Mug with hot water with 10% vinegar and let stand for 30 minutes. Rinse and wash with a soft sponge.


To Remove Coffee and Tea Stains:

To remove coffee and tea stains, we recommend using Zojirushi's cleaning detergent SB-ZA01E. Always remove the Lid Set when using SB-ZA01E. Contact Zojirushi Customer Service or your local dealer for further information.


How to Assemble & Disassemble the Lid Set

How to Disassemble

- ① Turn the Lid Cover as illustrated (counterclockwise) to remove.




- ② Remove the Seal Rubber with fingers.



- After removing the Lid Cover of the Lid Set, clean the Compartment as well.

How to Assemble


- ① Attach the Seal Rubber to the Lid (see next page "How to Attach the Seal Rubber").
- ② Turn the Lid Cover as illustrated (clockwise) to attach.



How to Assemble & Disassemble the Lid Set

How to Attach the Seal Rubber

Align the Concave Part of the Seal Rubber with Convex Part of the Lid and fit in by pressing the circumference of the Seal Rubber. Then press in the Seal Rubber from the outside towards center so that there is no gap between it and the Lid.



Replacing the Seal Rubber

The Seal Rubber may need to be replaced due to time and wear. Please check it about once a year. We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or its surface becomes rough, please replace them for optimum performance. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service.