




Household Use Only

## STAINLESS MUG Model SM-JTE Instruction Manual

### Name of Each Part



- The illustrations used in this instruction manual may differ from the actual product you have purchased.
- Please read these instructions before use, and keep for future reference.

### Warning

- Please follow these instructions to prevent injury, scalding, accidents, malfunction or performance deterioration of the product, spilling of beverages, etc.

Do not allow infants or small children to use this product. Keep out of the reach of infants and small children.

Do not attach parts other than those specifically designed for this product.

Always make sure that the parts are properly attached during use.


Do not use the product if its thermal insulation performance has deteriorated.



Leave 1cm (1/2-inch) room on top when filling the Main Body.

When using without the Tea Leaf Filter Set

Drink Level

When using with the Tea Leaf Filter Set




<p><b>Do not use if water enters the interior of the Vacuum Layer.</b></p> <p>If the internal water seeps out from the Vacuum Layer, drinking it may cause illness.</p>  <p>Vacuum Layer</p>	<p><b>Do not use this product for other than storing and keeping beverages hot or cold.</b></p> <p><b>Do not hold the product by the Lid Set when carrying because the product may fall and cause injuries.</b></p>
<p><b>When containing hot beverages:</b></p> <ul style="list-style-type: none"> <li>• Drink slowly without tilting the product suddenly.</li> <li>• The inside of the Lid Set is hot when touched from above. Therefore, do not use the product without the Lid Cover attached to the Lid Set.</li> <li>• Do not push the Mesh part when attaching the Tea Leaf Filter Set to the Main Body.</li> <li>• When removing the Tea Leaf Filter Set, please use caution as the Tea Leaf Filter Handle may be hot.</li> </ul>	<p><b>Do not attempt to carry the product by the Tea Leaf Filter Handle when the Tea Leaf Filter Set is attached to the Main Body.</b></p> <p><b>Make sure that there is no beverage leakage before using the product.</b></p> <p><b>Do not close the Lid Set while tea leaves or the string of a tea bag are caught in the gaskets.</b></p>
<p><b>Do not disassemble the product (other than parts designed to be disassembled).</b></p>	<p><b>Avoid dropping or hitting against hard surfaces.</b></p>
<p><b>Do not heat in a microwave, as doing so may cause sparks.</b></p>	<p><b>Never remove the sticker on the bottom of the Main Body.</b></p>  <p>Sticker</p>
<p><b>Do not place near open flames (from gas stoves, etc.), on top of electric heaters, or IH cooking devices, as doing so may cause a fire or malfunction.</b></p>	<p><b>Thoroughly clean the inside and outside of the Main Body (mouth) , Stopper, Tea Leaf Filter Set, and Gaskets after every use. Be particularly careful after filling the product with sports drinks.</b></p>
<p><b>When pouring hot beverages into the Main Body, be careful not to let it tip over.</b></p>	
<p><b>Do not drink out of the product while driving.</b></p>	
<p><b>When a vehicle drink holder is available:</b></p> <ul style="list-style-type: none"> <li>• Make sure that the product sits securely inside the drink holder.</li> <li>• Do not use a hanging-type drink holder that attaches to the window or air vent.</li> </ul>	<p><b>Do not place near heat sources such as gas stoves, ovens, and heaters, as doing so may cause deformation or discoloration of the product.</b></p> <p><b>Break ice cubes into smaller pieces, as failure to do so may cause deformation of the Main Body and leakage.</b></p>
<p><b>Consume beverages within the same day.</b></p> <p>Spoiled beverages may produce gas, raising the pressure inside the product and causing the Lid Set to burst.</p>	<p><b>Place the product vertically when carrying it in a bag to prevent leakage or condensation.</b></p>
<p><b>Never fill the product with the following:</b></p> <ul style="list-style-type: none"> <li>• Dry ice or carbonated drinks</li> <li>• Liquids high in sodium such as soup or Koby-cha</li> <li>• Dairy products or fruit juice</li> <li>• Fruit pulp</li> </ul>	<p><b>This product is designed to be drunk directly, so the beverage may splash if it is used for pouring.</b></p> <p><b>Do not scratch or rub the design on the outside of the Main Body strongly using fingernails or hard objects, as this may cause the design to come off.</b></p>
<p><b>Note: The rattling noise that may be heard when the Main Body is shaken comes from the metallic foil used in the vacuum insulation to increase heat (cold) retention, and does not indicate a malfunction.</b></p>	

## How to Use

### 1 Remove the Lid Set and the Tea Leaf Filter Set from the Main Body.

- ① Remove the Lid Set from the Main Body by turning it in the direction of the arrow.
- ② Hold the Tea Leaf Filter Set by the Tea Leaf Filter Handle and remove it from the Main Body.




### 2 Place tea leaves in the Main Body, and then fill it with hot water and attach the Tea Leaf Filter Set.

- Please fill hot water (beverages) up to the **Drink Level** on p. 1.
- Always make sure that the Tea Leaf Filter Set is attached securely during use.
- Adjust the amount of tea leaves according to taste.



### 3 Drink the beverage with the Tea Leaf Filter Set attached.

- Please drink with the Tea Leaf Filter Handle folded down.
- Tea leaves finer than the mesh of the Tea Leaf Filter Set may become mixed into the beverage.




## How to Disassemble the Parts

### ■ Tea Leaf Filter Set

#### Remove the Tea Leaf Filter Gasket.


Remove the Tea Leaf Filter Gasket from the recess using a blunt-tipped stick, etc.



### ■ Lid Set

#### 1 Remove the Lid Cover.


Place your finger on the Tab and pull apart in the directions of the arrows.



## How to Disassemble the Parts, continued


### 2 Remove the Stopper.

Using your fingers, push the two Tabs of the Stopper in the directions of the triangles (▷ and ◁) to remove the Stopper.




### 3 Remove the Lid Cover Gasket.


Remove the Lid Cover Gasket utilizing the Small Opening.



### 4 Remove the Valve Packing.



### 5 Remove the Stopper Gasket.




## How to Assemble the Parts


### ■ Tea Leaf Filter Set

#### 1 Attach the Tea Leaf Filter Gasket.

Attach the Lid Cover Gasket with the ridge facing out.



#### 2 Push the Tea Leaf Filter Set to attach




## How to Assemble the Parts, continued

### ■ Lid Set


#### 1 Attach the Stopper Gasket.

Line up the recess in the Stopper Gasket with the ridge on the Stopper, and, firmly applying pressure from the outside, push it into place.




#### 2 Attach the Valve Packing.

Firmly push the knob of the Valve Packing all the way into the hole in the center of the Stopper.




#### 3 Attach the Lid Cover Gasket.

Attach the Lid Cover Gasket with the ridge facing out.




#### 4 Attach the Stopper.

Align the two Tabs of the Stopper with the recesses of the Stopper Cover and press the Stopper in to attach it.



#### 5 Attach the Lid Cover.



## How to Take Care of Your Product:

- Follow the instructions for care and wash the product thoroughly before use.
- When you first use the product, there may be a plastic smell. However, this will become less noticeable with use.
- Clean the product after each use to prevent odors and mold, and to keep the product sanitary.
- Always disassemble the product before cleaning.

### When Cleaning Your Product:

- Do not boil or use a dishwasher or dish-dryer.
- Do not clean using paint thinner, polishing powders, abrasive cleansers, scrub brushes (nylon, metal wire, etc.), melamine sponges, the nylon side of an abrasive sponge, or any similar items.
- Do not use bleach as it may damage the product.  
Zojirushi's designated cleaning detergent SB-ZA01E may be used to clean the interior of the Main Body, Stopper, Tea Leaf Filter Set, and gaskets.
- The Main Body is fully washable, but do not soak it in water for an extended period of time.
- If the product is not going to be used for an extended period, wash thoroughly and dry well. Store the product away from high temperatures and humidity.

### Regular Care

- ① Using mild kitchen detergent diluted with lukewarm water, wash the Lid Set, the Tea Leaf Filter Set and the outside of the Main Body with a sponge, and the inside of the Main Body with a soft sponge with a handle.  
Use a small brush if necessary.
  - ② Rinse, wipe away remaining water, and leave to dry thoroughly.
- Streaks or smudges caused by rubbing on the coated portion of the Main Body can be removed using a soft eraser.

### Dealing with Stubborn Dirt

<b>Rust Spots and Water Stains</b>	<ol style="list-style-type: none"><li>① Fill the Main Body with hot water with 10% vinegar without attaching the Lid Set.</li><li>② After 30 minutes to an hour, wash the interior thoroughly.</li></ol>
<b>Tea and Coffee Stains</b>	Remove the Lid Set and use Zojirushi's cleaning detergent SB-ZA01E. (Contact Zojirushi Customer Service or your local dealer for further information.)

### Replacing the Stopper, Tea Leaf Filter Set, and Gaskets:

We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or their surface becomes rough, please replace them for optimum performance. The Stopper, Tea Leaf Filter Set and other consumable parts may need to be replaced due to time and wear. Please check them about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.