




STAINLESS MUG

Model
SM-M /
SM-Z / SM-G

Household Use Only

Instruction Manual

Name of Each Part



- Please read these instructions before use, and keep for future reference.
- The illustrations used in this instruction manual may differ from the actual product you have purchased.

SM-M/Z/G (J/T/E/K/C) / A

Important Safeguards

Be sure to follow the instructions.

These WARNINGS and CAUTIONS are intended to prevent property damage or personal injury to you and others.

■ The degree of danger or damage by the misuse of the product is indicated as follows:



WARNING

Indicates risk of serious injury or death.



CAUTION

Indicates risk of injury or property damage if mishandled.

■ Prohibited or required actions are indicated as follows:



Indicates a prohibited operation.



Indicates a requirement or instruction that must be followed.



WARNING



Do not allow infants or small children to use this product. Keep out of the reach of infants and small children.



CAUTION



Do not attach parts other than those specifically designed for this product.



Do not disassemble the product.



Always close the Lid securely.



Do not heat in a microwave, as doing so may cause sparks.



Do not use the product if its thermal insulation performance has deteriorated.



Do not place near open flames (from gas stoves, etc.), on top of electric heaters, or IH cooking devices, as doing so may cause a fire or malfunction.



When containing hot beverages:

- Drink slowly without tilting the product suddenly.




When pouring hot beverages into the Main Body, be careful not to let it tip over.



Do not use if water enters the interior of the Vacuum Layer.

If the internal water seeps out from the Vacuum Layer, drinking it may cause illness.

Vacuum Layer



Do not drink out of the product while driving.




Fill the Main Body only up to the level shown in the illustration.

Drink Level

Leave a bit of space below the rim (part A).


Inside of the Main Body



When a vehicle drink holder is available:

- Make sure that the product sits securely inside the drink holder.
- Do not use a hanging-type drink holder that attaches to the window or air vent.

⚠ CAUTION

<p>! Consume beverages within the same day. Spoiled beverages may produce gas, raising the pressure inside the product and causing the Lid Set to burst.</p>	<p>! Thoroughly clean the inside and outside of the Main Body (mouth), Lid, and Gasket after every use. Be particularly careful after filling the product with sports drinks.</p>
<p>⊘ Never fill the product with the following:</p> <ul style="list-style-type: none"> • Dry ice or carbonated drinks • Liquids high in sodium such as soup or Kobu-cha • Dairy products or fruit juice • Fruit pulp or tea leaves 	<p>⊘ Do not place near heat sources such as gas stoves, ovens, and heaters, as doing so may cause deformation or discoloration of the product.</p>
<p>⊘ Do not use this product for other than storing and keeping beverages hot or cold.</p>	<p>! Break ice cubes into smaller pieces, as failure to do so may cause deformation of the Main Body and leakage.</p>
<p>⊘ Do not hold the product by the Lid when carrying because the product may fall and cause injuries.</p>	<p>! Place the product vertically when carrying it in a bag to prevent leakage or condensation.</p>
<p>! Make sure that there is no beverage leakage before using the product.</p>	<p>⊘ This product is designed to be drunk directly, so the beverage may splash if it is used for pouring.</p>
<p>⊘ Avoid dropping or hitting against hard surfaces.</p>	<p>⊘ Do not scratch or rub the design on the outside of the Main Body strongly using fingernails or hard objects, as this may cause the design to come off.</p>
<p>⊘ Do not remove the sticker on the bottom of the Main Body.</p> <div style="text-align: right;">  <p>Sticker</p> </div>	

Note: The rattling noise that may be heard when the Main Body is shaken comes from the metallic foil used in the vacuum insulation to increase heat (cold) retention, and does not indicate a malfunction.

How to Take Care of Your Product:

- Thoroughly clean the product before use.
- When you first use the product, there may be a plastic smell. However, this will become less noticeable with use.
- Clean the product after each use to prevent odors and mold, and to keep the product sanitary.

When Cleaning Your Product:

- Do not boil or use a dishwasher or dish-dryer.
- Do not clean using paint thinner, polishing powders, abrasive cleansers, scrub brushes (nylon, metal wire, etc.), melamine sponges, the nylon side of an abrasive sponge, or any similar items.
- Do not use bleach as it may damage the product.
Zojirushi's designated cleaning detergent SB-ZA01E may be used to clean the interior of the Main Body and the Lid.
- The Main Body is fully washable, but do not soak it in water for an extended period of time.
- If the product is not going to be used for an extended period, wash thoroughly and dry well. Store the product away from high temperatures and humidity.

Regular Care

- ① Using warm water and mild dishwashing liquid, wash the Lid and the outside of the Main Body with a sponge, and the inside of the Main Body with a soft sponge with a handle.
Use a small brush if necessary.
 - ② Rinse, wipe away remaining water, and leave to dry thoroughly.
- Streaks or smudges caused by rubbing on the coated portion of the Main Body can be removed using a soft eraser.

Dealing with Stubborn Dirt

Rust Spots and Water Stains	<ol style="list-style-type: none">① Fill the Main Body with hot water with 10% vinegar without attaching the Lid.② After 30 minutes to an hour, wash the interior thoroughly.
Tea and Coffee Stains	Remove the Lid and use Zojirushi's cleaning detergent SB-ZA01E. (Contact Zojirushi Customer Service or your local dealer for further information.)

Replacing the Lid:

We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or their surface becomes rough, please replace them for optimum performance. The Lid may need to be replaced due to time and wear. Please check it about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.