




Household Use Only

STAINLESS MUG Model SM-SHE/SM-SHF

Instruction Manual

Name of Each Part



- Be sure that all parts are attached firmly before each use.

● The illustrations used in this instruction manual may differ from the actual product you have purchased.

Please read these instructions before use, and keep for future reference.

SM-SHE / SM-SHF (E/K) / B

Important Safeguards

- Please follow these instructions to prevent scalding, deterioration and discoloration of beverages, as well as malfunction and staining of the Mug.

Consume beverages within the same day.

Not doing so may cause spoiling. In addition, if left inside for a long period of time, spoiled beverages may produce gas, raising the pressure inside the Mug and causing the Lid Set to burst or beverages to spill, resultin

Do not remove the sticker on the bottom of the Main Body.

Doing so may cause rust or holes.

When filling the Mug with sports drinks:

- In order to prevent rusting and/or pinholes, rinse the inside and outside of the Main Body and the Lid Set immediately after consumption.
- Clean the inside using a soft sponge to protect from getting scratched.

Important Safeguards continued

Clean the Main Body after every use.

Not cleaning thoroughly may cause the Main Body to rust, beverages to spoil, or cause pinholes.


This Mug is for storing and keeping beverages hot or cold.

Please do not use for other than intended purposes.

Warnings & Cautions

Do not allow hot kettles to touch the Mouth of the Main Body.

The Main Body may tip over, causing scalds.



Do not leave a tea bag inside and set the Lid Set.

The tea bag may swell and cause leakage or cause drinks to spill out.

Do not force large ice cubes in. Break them into smaller pieces instead.

Doing so may cause deformation or damage to the product.

Avoid dropping or hitting against hard surfaces.

Damage to the plastic or stainless steel surface of the Mug may reduce its ability to retain heat.

Do not hold the Mug by the Lid Set or the Lid Cover when carrying.

The Mug may fall and cause injuries.

Hot tea may discolor if stored for a long period of time. We recommend the use of tea bags and brewing right before consumption.

Always clean the Stopper, Lid Cover Gasket and Stopper Gasket thoroughly after use.

Not doing so may cause decay, mold, odor or discoloration. It may also cause leaks.

Do not scratch or rub the design on the outside of the Main Body strongly using fingernails or hard objects.

This may cause the design to come off.

Do not attach parts other than those specifically designed for this product.

Doing so may cause leaks or breakage.

Placing ice cubes in the Mug may cause the internal pressure to decrease and the Lid Cover Gasket may come off when opening the Lid Cover. If this happens, please reattach the Lid Cover Gasket.

If a cold beverage is put into the product under highly humid conditions, condensation may form on the Lid Set. Stand the product upright when placing it in bags.

Always disassemble the Lid Set when washing and wipe dry (see pg.7).

Water may drip out if it is not dried well.

The rattling noise that may be heard when the Main Body is shaken comes from the copper or aluminum foil in the vacuum insulation to increase heat (cold) retention and does not indicate a malfunction.


This product is designed to be drunk from directly. If it is used for pouring, the beverage may splash.

How to Use:

- Follow the instructions for care and wash the Lid Set, the inside and outside of the Main Body thoroughly before use.
- When you first use the product, there may be a plastic smell. However, this will become less noticeable with use.


1 Remove the Lid Set from the Main Body.

Remove the Lid Set from the Main Body by turning it counterclockwise as illustrated.



2 Fill the Main Body with beverage.

For better heat retention, preheat or precool the Main Body with hot water (cold water) for about one minute, and then fill it with your beverage.




3 Set the Lid Set securely.

Close the Lid Cover, lock the Safety Lock* then turn the Lid Set clockwise as illustrated to set.


*See illustration 4 below.

- Confirm that the Stopper Gasket and Lid Cover Gasket are correctly attached before using. (If not correctly attached, the beverage may leak.)
- Firmly attach the Lid Set to the upright Main Body, lining up the Zojirushi logo mark with the front of the Lid Set.
- Attach the Lid Set properly and turn the Mug upside down to make sure contents do not leak.



4 Unlock the Safety Lock.

Slide the Safety Lock to the right (🔒) to unlock.




How to Use:

- Follow the instructions for care and wash the Lid Set, the inside and outside of the Main Body thoroughly before use.
- When you first use the product, there may be a plastic smell. However, this will become less noticeable with use.


5 Open the Lid Cover.

Push the Button and release to open the Lid Cover.

The Lid Cover may open slightly.




Opens



6 Drink the beverage.

- Do not tilt the Mug suddenly when drinking. (The beverage may spill and cause scalding or stain clothes.)



7 Close the Lid Cover and lock.

- ① With the Mug at an upright position, close the Lid Cover until it clicks.
- ② Slide the Safety Lock to the left to lock (see pg.5 illustration 4).

- Do not leave the Mug with the Lid Cover open.
- Always close the Lid Cover securely at an upright position.

Close securely until it clicks.



- Store the Mug upright when carrying inside bags to prevent beverages from spilling.




How to Disassemble & Assemble the Lid Set:

- Be sure to attach the Stopper Cover Set, Lid Cover Gasket, Stopper and Stopper Gasket correctly to prevent malfunction or leaking of beverages.


How to Disassemble:

1 Remove the Lid Set from the Main Body.

2 Remove the Stopper.
With the Lid Cover open, hold the Lid Set as illustrated, and press on the back of the Sip Area (parts indicated by the ▽ marks) to remove the Stopper.




3 Remove the Stopper Gasket.



Stopper Gasket

4 Remove the Lid Cover Gasket.


Pinch the edge of the Lid Cover Gasket as illustrated and pull it toward you to remove.



Lid Cover Gasket

How to Assemble:

1 Attach the Stopper Gasket. Line up the recess in the Stopper Gasket with the ridge on the Stopper, and, applying pressure from the outside in, push it into place.




Be careful with the top and the bottom of the gasket and be sure to set correctly. Not doing so may cause beverages to leak.

Push along the rim with your finger.

2 Attach the Lid Cover Gasket.
Align the Small Opening on the Lid Cover Gasket with the protrusion on the Lid Cover and press to attach.

- Be sure to set the Lid Cover Gasket before use.





How to Disassemble & Assemble the Lid Set:

- Be sure to attach the Stopper Cover Set, Lid Cover Gasket, Stopper and Stopper Gasket correctly to prevent malfunction or leaking of beverages.

3 Attach the Stopper.

Align the opening of the Lid Cover Set and the tab of the Stopper, and press the Stopper in to attach securely.



How to Take Care of Your Mug: ● Clean the product after each use to prevent odors and mold, and to keep the product sanitary.

- Always disassemble the product before cleaning. (see pg.7)

Exterior Lid Set

- ① Wash with warm water and mild dishwashing liquid using a soft sponge.
- ② Rinse, shake a few times and wipe dry.
 - When washing the Lid Set, disassemble it first then wash and dry.
 - Use a small brush sold in stores if necessary.

Interior

- ① Wash with warm water and mild dishwashing liquid using a soft sponge with handle.
- ② Then rinse and wipe moisture out to dry.

When Cleaning Your Product:

To protect the paint, print or stickers on the outside of the Main Body:

- Do not use a dishwasher or dish-dryer. Do not boil to sanitize.
- Do not use bleach on the outside of the Main Body.
- Do not clean using paint thinner, metal wire scrub brushes, scrubbing brushes that include abrasive cleaners, polishing powders, cleansers, melamine sponges, or any similar items.
- Do not use chlorine type bleach.
- Do not soak in water for an extended period of time.
- Wipe moisture off thoroughly to prevent water stains or rusting.
- If the product is not going to be used for an extended period, wash thoroughly with cold or lukewarm water and dry well. Store the product away from high temperatures and humidity.
High temperatures and humidity may damage the product.

How to Take Care of Your Mug: continued

To Remove Rust Spots and Water Stains:

You may find rust spots or water stains caused by impurities in the water. To remove these stains, fill the Main Body with hot water with 10% vinegar and let it stand for 30 minutes to an hour without attaching the Lid Set, then wash the interior thoroughly.

To Remove Coffee and Tea Stains:

To remove coffee and tea stains from the interior and the Lid Set, we recommend using Zojirushi's cleaning detergent SB-ZA01E. Always remove the Lid Set when using SB-ZA01E. Contact Zojirushi Customer Service or your local dealer for further information.

Replacing the Lid Cover Gasket, Stopper or Stopper Gasket:

We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or its surface becomes rough, please replace them for optimum performance. The Stopper may need to be replaced due to time and wear. Please check them about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.

SPECIFICATIONS:

Product: STAINLESS MUG

Model No.	Capacity	Weight	Heat Retention (Above)	Cold Retention (Below)
SM-SHE48 SM-SHF48	16 oz. (0.48 liter)	9 oz. (0.24 kg)	187°F (86°C) @ 1 hr. / 158°F (70°C) @ 6 hrs.	46°F (8°C) @ 6 hrs.
SM-SHE60	20 oz. (0.6 liter)	10 oz. (0.27 kg)	189°F (87°C) @ 1 hr. / 162°F (72°C) @ 6 hrs.	46°F (8°C) @ 6 hrs.

Heat/Cold Retention Testing Conditions:

At a room temperature of 68°F±4°F (20°C±2°C), the Main Body is filled with hot or cold water up to the level illustrated in **Drink Level** on p. 3, and left standing in an upright position. For heat retention, once the hot water reaches 203°F±2°F (95°C±1°C), the temperature is measured after 1 hour and 6 hours. For cold retention, once the cold water reaches 39°F±2°F (4°C±1°C), the temperature is measured after 6 hours.

Materials: Inner Liner	Stainless Steel
Exterior	Stainless Steel (Acrylic Resin Painted)
Mouth	Stainless Steel
Stopper	Polypropylene
Lid Cover	Polypropylene
Gasket	Silicone

Manufacturer: Zojirushi Corporation

Address: 1-20-5 Tenma, Kita-ku, Osaka 530-8511, Japan